



QuickStep Doormat with Frame

Product description

The fitted doormat ensures a perfect finish. The mat has 3 cleaning zones and a dirt collection zone and provides maximum protection for your floor.

Content:

- 6 Screws and plugs
- Fitted doormat with 3 cleaning zones
- Prefab frame (can be used with all QuickStep® floors)

Packing Unit: 1

Dimensions:

- Frame: 478 x 790mm / 18.8 x 31.1 In. (external dimensions)
- Doormat: 434 x 746mm / 17.09 x 29.37 In. (Thickness: 9mm/ 0.35 In.)



Applications

Thanks to this new fitted doormat, it's even more interesting to install QuickStep® in the entry hall or the conservatory. The three cleaning zones ensure that all the dirt remains in the mat.

Characteristics

- √ Optimum protection of your QuickStep® floor with the QuickStep® Doormat at the entrance of your home, you can avoid unnecessary damage to your floor. The scraping zone of the mat loosens the dirt. Coarse dirt such as grit is already removed from shoes in this zone. This brushing zone removes all fine dirt (e.g. sand) which has been loosened in the scraping zone. The drying zone removes any moisture. This means your high-quality QuickStep® floor will look like new for years.
- √ Easy to clean The QuickStep® Doormat has collection zones for the removed dirt so you can easily clean the mat. You can shake out the mat, clean it with the vacuum cleaner or even with a high-pressure cleaner (max. 100°C/212°F).
- √ Easy to fit The prefab frame can be used with all QuickStep® floors. The high-quality frame is designed to fit the dimensions of QuickStep® Eligna and QuickStep® Perspective floors, which makes installation even faster.
- √ Suitable for spaces with underfloor heating. The QuickStep® Doormat is suitable for spaces with underfloor heating.
- √ Does not obstruct the door from opening. The thickness of the QuickStep® Doormat perfectly matches the height of your floor, which means that the door is not obstructed when being opened. (The height is adjustable depending on the force with which the frame is attached to the subfloor.)

Instructions

1. First, install your floor (see installation instructions for QuickStep® floors). If necessary, saw the planks of the floor to the correct length so that the prefab frame fits into the open space. Leave space for the recommended expansion joint so your floor can still expand. (The frame is designed to fit the dimensions of QuickStep® Eligna and QuickStep® Perspective floors) (Tip: Leave a space of 468 by 780mm / 18.42 by 30.71 In.)
2. Put the prefab frame in the floor opening and attach the frame to the subfloor with the supplied screws and plugs. (The height is adjustable, depending on the force with which the frame is attached to the subfloor.) With 700 Uniclic and 800 Uniclic floors, cut and remove the underlay
3. Place the QuickStep® Doormat in the frame.

